

YANMAR

YANMAR CONSTRUCTION EQUIPMENT CO., LTD.


<https://www.yanmar.com>

0AKB3-EN0501
2023.11-0L



OPERATION & MAINTENANCE MANUAL EXCAVATOR **Vi080-7 (US) SV100-7 (US)**

YANMAR



OPERATION & MAINTENANCE MANUAL

EXCAVATOR

Vi080-7 (US)

(S/N 70501 & Above)

SV100-7 (US)

(S/N 70501 & Above)

YANMAR

Read this manual carefully to learn how to operate and service your machine correctly. Failure to do so could result in personal injury or machine trouble.

This manual is the permanent part of your machine, when you sell your machine, hand it together with machine.

This machine had been designed by metric. Accordingly, dimensions mentioned in this manual are metric.

Discrimination of right side and left side for the machine are determined based on the machine posture, in where the blade is in front. i.e. Right side of the operator is machine's right side when the operator seats toward the blade.

The machine operated and serviced correctly has the warranty that is the YANMAR product support program. However, in case of the abuse or modification without permission of YANMAR, the warranty does not become the subject and also product improvement program may not become the subject.

All information, illustrations and specifications in this manual are based on the latest product information available at the time of publication. The right is reserved to make changes at any time without notice.

REFERENCE INFORMATION

Write the correct information for your YANMAR Excavator in the spaces below.

Always use these numbers when referring to your YANMAR Excavator.

Model name : _____
Serial Number : _____
Engine Serial Number : _____

Your YANMAR Excavator Dealer : _____
Address : _____
Phone : _____

CALIFORNIA Proposition 65 WARNING

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

In case of exporting this product and providing the related technical material to non-residents in Japan or residents overseas, it is required to comply with the export and trade control laws and regulations of Japan and other relevant countries. Please be sure to follow the necessary procedure.

YANMAR AMERICA CORPORATION
101 International Parkway, Adairsville, GA 30103
TEL: (770) 877-7810 FAX: (770) 877-7565

For Emissions or Warranty Information:

Website: <http://us.yanmar.com/>
E- mail: CS_support@yanmar.com
Toll Free Telephone Numbers:
1-855-416-7091
1-800-872-2867

YANMAR CONSTRUCTION EQUIPMENT CO., LTD.

1717-1, Kumano, Chikugo-shi, Fukuoka, 833-0055, Japan
TEL: +81-942-53-5465 FAX:+81-942-53-5132

MAINTENANCE

1. Precautions for Servicing ...	186	First services	205
2. Basic Servicing Practices ...	188	Nonperiodic services	205
Diesel fuel	189	Checking before start-up	220
Engine oil	190	Maintenance every 50 service hours ...	221
Engine cooling water	191	Maintenance every 100 service hours...	222
Hydraulic oil and Reduction gear oil	193	Maintenance every 250 service hours...	222
Handling grease, oil, fuel and filters	193	Maintenance every 500 service hours...	227
Electrical equipment	194	Maintenance every	
Hydraulic system	194	1000 service hours	232
3. Consumables	196	Maintenance every	
4. Fueling, Oiling and Greasing		1500 service hours	237
Based on Temperature		Maintenance every	
Range	197	2000 service hours	237
Fuel and oil	197	Maintenance every	
Cooling water	197	3000 service hours	240
5. Standard Tightening Torque for		Maintenance every	
Bolts and Nuts	198	9000 service hours	240
Torque table	198		
6. Replacing Essential Parts			
Periodically	199		
7. Maintenance Table	201		
Table of service time intervals	201		
Service intervals when using			
the hydraulic breaker	204		
8. Procedures for			
Maintenance	205		

1. Precautions for Servicing

Do not use any inspection or servicing procedures that are not described and recommended in this manual.

Park the machine on solid, level ground to inspect and service it.

■ Check the hour meter

Read the hour meter every day to check if any service item has reached the time prescribed for implementation.

■ Use YANMAR genuine replacement parts

Use YANMAR genuine parts specified in the Parts Catalog.

■ Use YANMAR genuine lube oil and grease

Use YANMAR genuine lube oil and grease of specified viscosity for the operating temperature range.

■ Use clean lube oil and grease

Use clean lube oil, grease and containers and prevent dust from mixing into them.

■ Clean the machine

Clean the machine for easy isolation of faulty parts.

Particularly clean the grease nipple, breather, and the oil level gauge glass to prevent dust from entering into them.

■ Be careful of high water and oil temperatures

It is dangerous to replace the oil, the cooling water and the filter immediately after stopping the engine. Wait until their temperatures drop. When the engine oil is too cool, heat the oil to adequate temperature [approximately 68 °F to 104 °F (20 °C to 40 °C)] before draining oil to improve draining efficiency.

■ Check the drained oil and the old filter element

When replacing the engine oil, the hydraulic oil, or the filter element, check the drained oil and the old filter element for metallic dust and foreign solid deposits.

■ Observe precautions for replenishing oil

If a strainer is mounted on the oil port, do not remove the strainer to replenish oil.

■ Be careful of dust

When checking or replacing the oil, do this in a clean environment to prevent dust contamination.

■ Attach the warning tag

When the oil or the cooling water is being drained, attach the "SERVICING IN PROGRESS" tag to one of the control levers so that other persons will not start the engine.

■ Observe the warning labels

Observe the warning labels affixed to the machine.

■ Observe the precautions for welding

- Make sure to disconnect the battery cables (positive and negative terminals).
- Do not apply more than 200 V continuously.
- Ground the machine within 3.3 ft. (1000 mm) from the welded part.
- Make sure that there is no seal or bearing between the welded part and the grounded part.
- Do not ground around the pins on the implement or the hydraulic cylinder.

■ Be careful of fire

Clean parts with noncombustible detergent.

■ Clean mating surfaces before assembly

When you have removed a part with an O-ring or a gasket seal, clean the mating surfaces before installing the new part.

At this point, do not fail to refit the O-ring or the gasket.

■ Do not drop anything from your breast pocket

When you open the cover and attempt to look down into the inside of the machine, remove loose items from your breast pocket to eliminate the risk that they may drop into the machine.

■ Check the undercarriage

After the machine is used at a rocky place, check the undercarriage for damage. Check for loose bolts and nuts, cracks, wear, and other damage. Loosen the tension of the crawlers more than usual.

■ Observe the precautions for cleaning the machine

- Do not spray steam directly at the connectors.
- Do not splash water on the monitors in the cabin.
- Do not spray high-pressure water directly at the radiator and the oil cooler.

■ Check before and after working

If the machine is to be used in mud, rain, snow, or on a beach, check for loose plugs and cocks before working. After working, clean the machine and check each part for cracks and damage and check for loose or missing bolts and nuts. Apply grease earlier than usual. Particularly apply grease every day to the pins on the implement which are submerged in mud.

■ Observe the precautions for working in a dusty place

If you use the machine in a dusty place, be careful of the following:

- Check the air cleaner for clogging.
- Clean the air cleaner element earlier than scheduled.
- Clean the radiator fin earlier to prevent it from clogging.
- Clean or replace the fuel filter element earlier than scheduled.
- Clean the electric equipment, especially the starter motor and the generator, to avoid dust deposits.

■ Do not mix oils

Never mix oils of different makes or types. If you have to replenish an oil with a different make or type than the one already in the tank, remove the remaining oil completely.

2. Basic Servicing Practices

- Use YANMAR genuine replacement parts.
- Do not mix oils of different makes and types when replacing or replenishing oil.
- The following types of oil, fuel and cooling water are used at the factory for shipping unless otherwise specified:

Item	Type
Engine oil	Engine oil SAE10W30, CJ-4 class
Travel reduction gear oil	Gear oil SAE90 (GL-4)
Hydraulic oil	ISO VG46
Fuel	Diesel light oil (Ultra low sulfur)
Engine cooling water	YANMAR genuine long-life coolant (LLC) 51 % or 30 % + water 51 %: U.S.A., Canada, Australia and New Zealand 30 %: other countries

Diesel fuel

- Because the fuel injection pump is a precision device, using a fuel containing water or dust will cause problems.
- Be careful that impurities will not be mixed into the fuel especially after storing the machine and refueling.
- Be sure to use a fuel recommended in the Operation & Maintenance Manual.
In addition, keep in mind that you should use a fuel appropriate for the operating temperature range because it will freeze at temperatures lower than 5 °F (-15 °C).
- Fully refuel every day after finishing the work so that the moisture in the fuel tank will not condense and water will not mix with the fuel.
- Before starting the engine, or ten minutes after refueling, drain any deposits and water through the drain plug on the fuel tank.
- If the fuel level becomes low or the filter element is replaced, the air should be bled from the fuel system.

Diesel Fuel Specifications

Diesel fuel should comply with the following specifications. The table lists several world-wide specifications for diesel fuels.

Diesel fuel specification	Location
ASTM D975 No. 1D S15 No. 2D S15	USA
EN590:96	European Union
ISO 8217 DMX	International
BS 2869-A1 or A2	United Kingdom
JIS K2204 Grade No. 2	Japan
KSM-2610	Korea
GB19147-2016	China

Additional technical fuel requirements

- The fuel cetane number should be equal to 45 or higher.
- The sulfur content must not exceed 15 ppm by mass. A higher sulfur content fuel may cause sulfuric acid corrosion in the cylinders of the engines. Especially in U.S.A. and Canada, Ultra Low Sulfur fuel must be used.
- Never mix kerosene, used engine oil, or residual fuels with the diesel fuel.
- Water and sediment in the fuel should not exceed 200 mg/kg.
- Keep the fuel tank and fuel-handling equipment clean at all times.
- Poor quality fuel can reduce engine performance and/or cause engine damage.
- Fuel additives are not recommended. Some fuel additives may cause poor engine performance. Fuel additives containing alcohol content, such as drainage agent etc. have adverse effects on the sealing section, and it will result in fuel leaks. Consult your dealer for more information.
- Ash content not to exceed 0.01 % by mass.
- Carbon residue content not to exceed 0.35 % by mass. Less than 0.1 % is preferred.
- Total aromatics content should not exceed 35 % by volume. Less than 30 % is preferred.
- PAH (Polycyclic Aromatic Hydrocarbons) content should be below 10 % by volume.
- Metal content of Na, Mg, Si, and Al should be equal to or lower than 1 mass ppm. (Test analysis method JPI-5S-44-95)
- Lubricity: Wear mark of WS1.4 should be Max. 0.018 in. (460 µm) at HFRR test.
- Be sure to use fuel that does not contain zinc or sodium.
- Never use kerosene or fuel mixed with kerosene.

- Never use fuel that has been stored in a drum or the like for a long period of time.
- Be sure to use fuel purchased from authorized diesel fuel suppliers.

■ Bio-diesel fuels

In Europe and in the United States, as well as some other countries, non-mineral oil based fuel resources such as RME (Rapeseed Methyl Ester) and SOME (Soybean Methyl Ester), collectively known as FAME (Fatty Acid Methyl Esters), are being used as extenders for mineral oil derived diesel fuels.

YANMAR approves the use of bio-diesel fuels that do not exceed a blend of 7 % (by volume) of FAME with 93 % (by volume) of approved mineral oil derived diesel fuel. Such bio-diesel fuels are known in the marketplace as B7 diesel fuels.

These B7 diesel fuels must meet certain requirements.

1. The bio-fuels must meet the minimum specifications for the country in which they are used.
 - In Europe, bio-diesel fuels must comply with the European Standard for both EN14214 and EN590 (for Oxidation stability).
 - In the United States, bio-diesel fuels must comply with the American Standard for both ASTM D-6751 and ASTM D-7467 (for Oxidation stability).
2. Bio-fuels should be purchased only from recognized and authorized diesel fuel suppliers.

Precautions and concerns regarding the use of bio-fuels:

1. Free methanol in FAME may result in corrosion of aluminum and zinc FIE components.

2. Free water in FAME may result in plugging of fuel filters and increased bacterial growth.
3. High viscosity at low temperatures may result in fuel delivery problems, supply pump seizures, and poor injection nozzle spray atomization.
4. FAME may have adverse effects on some elastomers (seal materials) and may result in fuel leakage and dilution of the engine lubricating oil.
5. Even bio-diesel fuels that comply with a suitable standard as delivered, will require additional care and attention to maintain the quality of the fuel in the equipment or other fuel tanks. It is important to maintain a supply of clean, fresh fuel. Regular flushing of the fuel system, and/or fuel storage containers, may be necessary.
6. Use bio diesel fuel within 2 months after filling it to the fuel tank, or within 3 months after its production at the manufacturer. The use of bio-diesel fuels that do not comply with the standards as agreed to by the diesel engine manufacturers and the diesel fuel injection equipment manufacturers, or biodiesel fuels that have degraded as per the precautions and concerns above, may affect the warranty coverage of your engine.

Engine oil

- Only use the engine oil specified. Other engine oils may affect warranty coverage, cause internal engine components to seize and/or shorten engine life.
- Prevent dirt and debris from contaminating the engine oil. Carefully clean the oil cap/dipstick and the surrounding area before you remove the cap.

- Never mix different types of engine oil. This may adversely affect the lubricating properties of the engine oil.
- Never overfill. Overfilling may result in white exhaust smoke, engine overspeed or internal damage.

⚠ WARNING



Burn Hazard!

- **Wait until the engine cools before you drain the engine coolant. Hot engine coolant may splash and burn you.**
- **Failure to comply could result in death or serious injury.**

Engine Oil Specifications

Use an engine oil that meets or exceeds the following guidelines and classifications:

■ Service categories

- API service categories CJ-4
- ACEA service categories E6
- JASO service category DH-2

■ Definitions

- API classification (American Petroleum Institute)
- ACEA classification (Association des Constructeurs Européens d'Automobiles)
- JASO (Japanese Automobile Standards Organization)

Note:

- *Be sure the engine oil, engine oil storage containers, and engine oil filling equipment are free of sediments and water.*
- *YANMAR does not recommend the use of engine oil "additives."*

■ Additional technical engine oil requirements:

The engine oil must be changed when the Total Base Number (TBN) has been reduced to 1.0 mgKOH/g. TBN (mgKOH/g) test method; JIS K-201-5.2-2 (HCl), ASTM D4739 (HCl).

Engine cooling water

- Because unpotable water may contain much calcium and impurities, using it will cause water scale to build up in the engine or the radiator, causing poor heat exchange and overheating.
Never use unpotable water for cooling purposes.
- When using an anti-freeze, observe the precautions described in the Operation & Maintenance Manual.
- A YANMAR machine is shipped with YANMAR genuine anti-freeze. The anti-freeze is anticorrosive to protect the cooling system. Because the anti-freeze can be used continuously over two years, you need not remove it in hot weather.


⚠ DANGER

Keep sources of ignition away from the antifreeze because it is flammable.

- The mixing ratio of anti-freeze to water differs based on air temperature.
For the mixing ratio, refer to Section "Replacing the engine cooling water" on page 237.
- If the engine is overheated, replenish the cooling water after the engine has cooled down.
- Shortage of cooling water will cause the cooling system not only to overheat but also to corrode, due to air which comes in the system.

! DANGER**Scald Hazard!**

- **Never remove the radiator cap if the engine is hot. Steam and hot engine coolant will spurt out and seriously burn you. Allow the engine to cool down before you attempt to remove the radiator cap.**
- **Tighten the radiator cap securely after you check the radiator. Steam can spurt out during engine operation if the cap is loose.**
- **Always check the level of the engine coolant by observing the reserve tank.**
- **Failure to comply will result in death or serious injury.**

! CAUTION**Engine Coolant Hazard!**

- **Wear eye protection and rubber gloves when you handle long life or extended life engine coolant.**

If contact with the eyes or skin should occur, flush eyes and wash immediately with clean water.

- **Failure to comply may result in minor or moderate injury.**
- Only use the engine coolant specified. Other engine coolants may affect warranty coverage, cause an internal buildup of rust and scale and/or shorten engine life.
- Prevent dirt and debris from contaminating the engine coolant. Carefully clean the radia-

tor cap and the surrounding area before you remove the cap.

- Never mix different types of engine coolants. This may adversely affect the properties of the engine coolant.

Engine Coolant Specifications

Use a Long Life Coolant (LLC) or an Extended Life Coolant (ELC) that meets or exceeds the following guidelines and specifications.

Alternative engine coolant

If an Extended or Long Life Coolant is not available, alternatively, you may use an ethylene glycol or propylene glycol based conventional coolant (green).

Note:

- *Always use a mix of coolant and water. Never use water only.*
- *Mix coolant and water per the mixing instructions on the coolant container.*
- *The mix ratio of Long Life Coolant or anti-freeze to water should be from 30 to 60 %.*
- *Water quality is important to coolant performance. YANMAR recommends that soft, distilled or demineralized water be used to mix with coolants.*
- *Never mix extended or long life coolants and conventional (green) coolants.*
- *Never mix different types and/or colors of extended life coolants.*
- *Replace the coolant every 1000 engine hours or once a year.*

Additional technical coolant specifications:

- ASTM D6210, D4985 (US)
- JIS K-2234 (Japan)
- SAE J814C, J1941, J1034 or J2036 (International)

Hydraulic oil and Reduction gear oil

- Because the oil is used in the machine under extreme conditions (high temperature and pressure), it deteriorates as time elapses. Be sure to use oils of the grades which are specified in the Operation & Maintenance Manual and suitable for the operating temperature range. Even if the oil is not contaminated, be sure to replace the oil within the specified service hours.
- Oil is equivalent to blood in a human body. Be careful in handling it so that impurities (water, metallic dust, and foreign solids) will not be mixed into it. Most machine failures are caused by impurities in the oils. Be careful not to mix impurities into the oils especially after storing the machine and replenishing oils.
- Do not mix oils of different makes and types.
- Use the specified amount of oil. Use of larger or smaller amounts of oil than specified may cause machine problems.
- If the oil becomes cloudy, it may suggest that water or air could have been mixed into the hydraulic system. If this event happens, ask your dealer for assistance.
- Be sure to replace the oil filter element with a new one when changing the oil.
- To know what condition the machine is in, it is recommended that you analyze the properties of the oil periodically. Ask your dealer for more information on this issue.

Handling grease, oil, fuel and filters

Grease

- Grease ensures smooth operation of moving parts such as connectors and prevents operating noises.
- The nipples not listed on the pages for periodic service are those used for overhaul purposes. Normally it is not necessary to refill them. Grease them if any abnormal condition arises after long term use.
- Wipe away all excess grease after greasing. Carefully wipe the excess grease from all moving parts which might be easily worn by adhered sand or grit.

Storing the oil and fuel

- Store the oil and fuel indoors so that they are not be contaminated by impurities such as water or dust.
- When you store oil or fuel in drums for a long period, position them so that their outlets align in a straight line (to prevent moisture absorption). When storing the oil or the fuel outdoors, cover the drums with a waterproof sheet.
- To avoid deterioration caused by long-term storage, use the oil on a first-in first-out basis.

Filter

- The filters are very important parts which prevent impurities from getting into critical devices through the lube oil, fuel and air systems. Replace the filter elements periodically according to the instructions of the Operation & Maintenance Manual. Under difficult conditions, you need to

replace the filter elements earlier than suggested in the Operation & Maintenance Manual depending on the type of oil and fuel (sulfur content).

- Never reuse the filter elements (cartridge type) by cleaning them.
- When replacing a filter element, confirm that no metallic dust or foreign solids are present on the old filter.
If they are found to be present, contact the nearest dealer.
- Do not unpack the filter element before use.
- Use YANMAR genuine filter elements.

Electrical equipment

- If electrical equipment gets wet or wiring insulation is broken, electric leaks may occur and the machine may malfunction.
- Check the fan belt for tension and damage, and also check the battery.
- Never disconnect or disassemble the electrical equipment mounted on the machine.
- Do not mount any electrical equipment other than those items provided by YANMAR.
- Be careful not to spray water on the electrical equipment when washing the machine or operating in the rain.
- After working near the sea, take necessary precautions to protect the electrical equipment from corrosion.

Hydraulic system

- The hydraulic system is hot during and immediately after operation. It is also under high pressure during operation. Therefore, check and service the hydraulic system carefully as follows:

Retract the bucket and arm cylinders to place the bucket on the ground.




Fig. 2-1

- Put the bucket on level ground so that no pressure is applied to the hydraulic cylinder circuits.
- Be sure to stop the engine.
- Wait until the temperature drops sufficiently before starting maintenance.
- Release the pressure from the hydraulic circuit.

Handling accumulator: Refer to page 159.

- Do not suddenly remove any plugs, screws or connecting parts of the hoses. Otherwise oil may spout out due to residual internal pressure even when the oil temperature has lowered. Be careful not to stand in front of any plugs, screws or connecting parts when loosening them, to prevent injury. Loosen them gradually, to relieve the internal pressure.
- Always relieve the internal pressure before checking and servicing the hydraulic system.
- Check the hydraulic oil level, replace the filter element, and replace the hydraulic oil when necessary.
- After removing hydraulic hoses and piping, check the O-rings and the packing for damage before reinstalling them. Replace them if they are damaged.
- Bleed air after replacing or cleaning the hydraulic oil filter element or strainer, repairing or replacing the hydraulic equipment, or reinstalling the hydraulic cylinder or piping.

Bleed air according to the following procedure:

1. After operating the engine at low idle speed with no load for a couple of minutes, increase the engine speed to a middle speed.
 2. Slowly operate each cylinder 4 to 5 times to approximately 4 in. (100 mm) before both stroke ends.
 3. Operate the cylinder 4 to 5 times at full stroke.
- Failure to bleed air from the hydraulic cylinder and operating it suddenly to the stroke ends could cause piston seal damage.
 - If air is left in the hydraulic circuit, it will compress and expand and the hydraulic equipment will not operate smoothly. Air in the hydraulic circuit may shorten the service life of the hydraulic pump.

4. Check the hydraulic oil level and replenish hydraulic oil to the specified level if necessary.

Refer to Section "Checking and replenishing the hydraulic oil tank" on page 116.

3. Consumables

Replace consumable parts such as filter element and bucket teeth periodically or earlier than wear limit.

Replace consumable parts securely to use our product more economically.

When you replace a part, be sure to use a Yanmar genuine part.

When ordering consumables, let us know the part numbers given in the parts catalog.

■ List of consumables

<>: SV100-7 only

Item		Q'ty	Replacing time interval
Engine oil filter		1	Every 500 service hours
Fuel filter		1	Every 500 service hours
Fuel pre-filter element		1	Every 500 service hours
Air cleaner element	Outer	1	Every 500 service hours
	Inner	1	-
Hydraulic oil return filter element		1	Every 500 service hours (At first 250 service hours)
Hydraulic oil breather filter element		1	Every 500 service hours
Hydraulic oil line filter element		1	Every 1000 service hours
Bucket	Point teeth (Rubber)	4<5> (4<5>)	-
	(Pin)	(4<5>)	
	Side cutter (left)	1	
	Side cutter (right)	1	
	(Bolt 22×62)	(6)	
	(Nut 22)	(6)	

The numbers of parts in the parentheses represent those which must be replaced at the same time.

4. Fueling, Oiling and Greasing Based on Temperature Range

Fuel and oil

Select fuel and oil based on to the air temperature range.

The prescribed amount of oil means the total amount of oil included in the piping and equipment.

The amount of oil to be changed means the amount of oil replaced in checking and servicing.

If you start the engine at air temperatures lower than 32 °F (0 °C), use SAE10W, SAE10W-30, or SAE15W-40 even if the temperature in the daytime rises to 50 °F (10 °C) or so.

<>: SV100-7 only

Part to be refilled	Oil type	Recommendations with regard to temperature ranges						Prescribed amount of oil	Amount of oil to be changed	
		(°F) (°C)	-4 (-20)	-14 (-10)	32 (0)	50 (10)	68 (20)			86 (30)
Engine oil pan	Engine oil		SAE 10W CJ-4					11.8 Qts. (11.2 L)	11.8 Qts. (11.2 L)	
			SAE 10W-30 CJ-4							
			SAE 15W-40 CJ-4							
Travel reduction gear	Gear oil		SAE 90 (GL- 4)						1.16 <2.22> Qts. (1.1 <2.1> L) (For right and left each)	1.16 <2.22> Qts. (1.1 <2.1> L) (For right and left each)
Hydraulic oil system	Hydraulic oil		ISO VG46						In the tank 15.8 Gals. (60 L) Other parts 15.3 Gals. (58 L)	15.8 Gals. (60 L)
Fuel tank	Light oil	No. 1-D or No. 2-D diesel fuel						30.4 Gals. (115 L)	-	
Cooling system	Water	YANMAR genuine long-life coolant (LLC) added						Radiator	-	
								9.1 Qts. (8.6 L)		
								Subtank		
							0.4 Qts. (0.4 L)			

Cooling water

Because a YANMAR genuine long-life coolant (LLC) is added to the cooling water, you need not change it unless the temperature falls below -31 °F (-35 °C).

If the temperature falls below -31 °F (-35 °C), refer to Section "Replacing the engine cooling water" on page 237 to control the density of the cooling water.

5. Standard Tightening Torque for Bolts and Nuts

Torque table

Bolts or nuts in the metric system should be tightened at the torque described below unless otherwise specified.

Item		Thread size × pitch	Tightening torque ft•lbf (N•m)	Remarks
Hexagon bolt (7T) Nut	Coarse threads	M6 × 1	7.2 to 8.7 (9.8 to 11.8)	<ul style="list-style-type: none"> • Apply 80 % tightening torque when tightened to aluminum. • Apply 60 % tightening torque for 4T bolt and lock nut. • Use fine threads for engine only.
		M8 × 1.25	16.7 to 20.9 (22.6 to 28.4)	
		M10 × 1.5	32.5 to 43.4 (44.1 to 58.8)	
		M12 × 1.75	58 to 72.4 (78.5 to 98.1)	
		M14 × 2	86.8 to 108.5 (117.7 to 147.1)	
		M16 × 2	123 to 151.9 (166.7 to 206.0)	
		M18 × 2.5	173.6 to 209.8 (235.4 to 284.4)	
	M20 × 2.5	238.7 to 296.6 (323.6 to 402.1)		
	Fine threads	M14 × 1.5	94 to 108.5 (127.5 to 147.1)	
M16 × 1.5		155.5 to 177.2 (210.8 to 240.3)		
PT plug		1/8	7.2 (9.8)	-
		1/4	14.5 (19.6)	
		3/8	21.7 (29.4)	
		1/2	43.4 (58.8)	
Pipe joint bolt		M8	9.4 to 12.3 (12.7 to 16.7)	-
		M12	18.1 to 25.3 (24.5 to 34.3)	
		M14	28.9 to 36.1 (39.2 to 49)	
		M16	36.1 to 43.4 (49.0 to 58.8)	

IMPORTANT

If a part to be tightened is made of resin like a panel board, excessive tightening torque may damage the tightened part. Be careful when tightening.

6. Replacing Essential Parts Periodically

For safe operation, the machine must be serviced periodically. To increase safety, be sure to periodically replace the parts listed in the table of safety parts on the next page. A fire could result if they deteriorate or are damaged.

These parts are vulnerable to age and wear or deterioration and it is difficult to determine the degree to which they have deteriorated on the occasion of periodic service. To maintain their proper function at all times, therefore, replace them with new ones after using them for a specific period of time even if no abnormality is found with the parts.

If you find abnormalities in these parts before their scheduled replacement time is reached, repair or replace them immediately.

If a hose clamp is deformed or cracked, replace it immediately.

Check the hydraulic hoses (which are not periodic replacement parts). If any abnormality is found in them, retighten them or replace them immediately.

When replacing the hydraulic hoses, replace the O-rings and seals at the same time.

For further information about replacing the safety parts, ask your dealer.

Check the fuel and hydraulic hoses according to the periodic schedule described below.

Check categories	Check points
Start-up check	Oil leak from the connections or bodies of the fuel and hydraulic hoses
Voluntary monthly check	Oil leak from the connections or bodies of the fuel and hydraulic hoses Damage (crack, wear, or peeling) of the fuel and hydraulic hoses
Prescribed annual check	Oil leak from the connections or bodies of the fuel and hydraulic hoses Interference, crushing, aging, torsion, or damage (crack, wear, or peeling) of the fuel and hydraulic hoses

■ List of essential parts

No.	Essential parts to be replaced periodically	Q'ty	Replacement time intervals
1	Fuel hose (fuel tank to pre-filter)	1	Earlier of either every 2 years or every 2000 service hours
2	Fuel hose (pre-filter to feed pump)	1	
3	Fuel hose (feed pump to fuel filter)	1	
4	Fuel hose (fuel filter to supply pump)	1	
5	Fuel hose (fuel filter to fuel cooler)	1	
6	Fuel hose (fuel cooler to fuel tank)	1	
7	Fuel hose (fuel filter to joint)	1	
8	Fuel hose (joint to supply pump)	1	
9	Fuel hose (common rail to joint)	1	
10	Fuel hose (injectors to joint)	1	
11	Main pump outlet hose (P1, P2, P3 to C/V)	2	

7. Maintenance Table

Daily and periodic inspection are important to keep the machine in its best condition. The following is a summary of inspection and servicing requirements by inspection interval. Periodic inspection intervals vary depending on the use, loads, fuels and lube oils used and handling conditions, and are hard to establish definitively. The following should be treated only as a general standard. When the time for an inspection approaches, study the relevant pages in the Operation & Maintenance Manual. Keep a record of daily operation and the results of maintenance work.

Table of service time intervals

Check and service points	Page
--------------------------	------

■ Checking before start-up

Walking check (visual inspection) around the machine	111
Checking and replenishing the cooling water	112
Checking and draining the pre-filter	113
Checking and replenishing the engine oil	114
Checking and replenishing the fuel in the fuel tank	115
Checking and replenishing the hydraulic oil tank	116
Greasing	117
Checking the electrical equipment	119

■ Nonperiodic servicing

Checking the rubber crawlers (for rubber crawler types)	205
Checking and adjusting the rubber crawler tension	207
Replacing the rubber crawler	210
Checking and adjusting the steel crawler tension	212
Replacing the bucket teeth and side cutter	215
Replacing the bolt-on cutting edge (bolt-on cutting edge type)	217
Maintenance, inspection and servicing of air conditioner	218
Cleaning the cabin floor	219
Checking the gas spring	219
Checking and cleaning DPF soot filter	Ask your dealer

■ List of periodic inspection and servicing

◇ : Check ○ : Supply ● : Replace □ : Adjust (clean) ■ : Oil & grease

Check & service items		Every 50 hrs	Every 100 hrs	Every 250 hrs	Every 500 hrs	Every 1000 hrs	Every 1500 hrs	Every 2000 hrs	Every 3000 hrs	Every 9000 hrs	Page
Fuel oil	Fuel tank	□									221
	Pre-filter				●						227
	Fuel filter element				●						228
	Fuel cooler			□							
	Fuel hose							● (within two years)			
Lube oil	Engine oil				●						229
	Engine oil filter				●						
	Engine oil hose							◇ (within two years)			229
	Travel reduction oil		● (1st time)	◇		●					
Cooling water	Cooling water							● (within two years)			237
	Radiator			□							
	Cooling water hose							◇ (within two years)			
Hydraulic system	Hydraulic oil					●					234
	Suction filter					□					
	Return filter			● (1st time)	●						
	Breather filter				●						
	Line filter					●					
	Oil cooler			□							
	Hydraulic hose							● (within two years)			
	Accumulator							◇			
Upper-structure	Swing gears and swing bearings	■									
Engine	Air cleaner			□	●						
	Compressor belt	◇ (1st time)		◇							
	Fan belt	◇ (1st time)		◇							
	Valve clearance					□					
	Valve sheet							◇ (As required)			
	EGR valve								□		
	EGR cooler						□				
	Crankcase breather system						◇				
	Breather hose							◇ (within two years)			
	Intake throttle								◇		
	Injector								◇		
	Diesel particulate filter (DPF)									●	

◇ : Check ○ : Supply ● : Replace □ : Adjust (clean) ■ : Oil & grease

Check & service items		Every 50 hrs	Every 100 hrs	Every 250 hrs	Every 500 hrs	Every 1000 hrs	Every 1500 hrs	Every 2000 hrs	Every 3000 hrs	Every 9000 hrs	Page
Air con- ditioner	Condenser			□							

Service intervals when using the hydraulic breaker

When a hydraulic breaker is used, the hydraulic oil deteriorates earlier than in usual bucket excavating work. Set up the service time intervals as follows:

- **Replacing the hydraulic oil return filter element**

Replace the hydraulic oil return filter element after 100 to 150 hours only at initial time for a new machine. After that, replace it in accordance with the chart at the **Fig. 7-1**.

- **Replacing the hydraulic oil in the hydraulic oil tank**

Replace the hydraulic oil in accordance with the chart at the **Fig. 7-1**.




Fig. 7-1

8. Procedures for Maintenance

First services

Service it as follows only at the initial time for a new machine.

■ At first 100 hours

Replacing the lube oil for the travel reduction gearbox.

For this procedures, refer to Section "Maintenance every 1000 service hours".

■ At first 250 hours

Replacing hydraulic return filter element.

For this procedure, refer to Section "Maintenance every 500 service hours".

Nonperiodic services

Checking the rubber crawlers (for rubber crawler types)

Rubber crawlers in the following condition require repair or replacement. Ask your dealer to repair or replace them.

■ Height of lugs

- As the lug height "a" is reduced by wear, the tractive force decreases.

If "a" becomes 0.2 in. (5 mm) or less, replace the crawler with a new one.




Fig. 8-1

- If two or more links of the steel cord inside the crawler are exposed due to wear of the lugs, replace the crawler with a new one.




Fig. 8-2

■ Rubber crawler steel cord breakage

If half or more of either of the steel cords is broken, replace the rubber crawler with a new one.




Fig. 8-3

■ Separation of the core metal of the rubber crawler

If the core metal of the rubber crawler separates even at one place, replace the rubber crawler with a new one.




Fig. 8-4

■ Rubber crawler tension

If the rubber crawler tension is habitually loose even after grease is injected, the grease adjuster may be defective internally. Ask your dealer to repair the grease adjuster.

■ Crack in the rubber crawler

If a crack occurs between any lugs of the rubber crawler, repair it if the crack length reaches approximately 2.4 in. (60 mm). If the inside steel cord is exposed even though the crack is small, repair the rubber crawler immediately. If the crack length is less than 1.2 in. (30 mm) or the crack depth is less than 0.4 in. (10 mm), you do not need to repair the rubber crawler. For a decision on whether the rubber crawler should be replaced, repaired or should continue to be used, ask your dealer.




Fig. 8-5

Checking and adjusting the rubber crawler tension

⚠ WARNING

- When adjusting the rubber crawler tension while raising the machine, do not support the machine with the implement only.
The control levers could move or the hydraulic oil could flow out accidentally so that the machine would fall.
- When raising the machine, support it with safety blocks of sufficient strength.
When the machine is being checked or adjusted by two persons, one must operate the machine in response to signs from the other.

How a rubber crawler wears out depends on the working conditions and the nature of the ground. Be sure to check the rubber crawlers for wear and tension from time to time. When a new rubber crawler is mounted, perform the first check after 30 hours operation.

■ Checking the rubber crawler tension

1. Move the machine so that the joint ( mark) on the inside surface of the rubber crawler is positioned at the upper center of the track frame.




Fig. 8-6

2. Lift the machine with the implement and the safety blocks.
To do this, operate the control lever slowly.




Fig. 8-7

3. The tension is proper if the clearance (H in the figure below) between the middle track roller rim and the rubber crawler is 0.8 to 1.0 in. (20 to 25 mm).




Fig. 8-8

Working with the rubber crawler too loose will cause the rubber crawler to come off or the core metal to wear out earlier.

If the tension is improper, adjust it as follows:

■ **Adjusting the rubber crawler tension**

• **To increase the tension**

Prepare a grease gun.

1. Remove the cover.




Fig. 8-9

2. Raise the machine using the implement and the safety blocks. Inject grease through the nipple valve (**Fig. 8-11, 1**) using a grease gun until the rubber crawler tension has achieved a clearance (H) that is within the following range: 0.8 to 1.0 in. (20 to 25 mm).




Fig. 8-10




Fig. 8-11

3. To check that the tension is proper, lower the machine and move the machine back and forth slightly.

4. Check the rubber crawler tension again. If the tension is improper, adjust it again.

5. Install the cover.

6. The tension is adjustable until the clearance "a" is reduced to 0 in. (0 mm). If the tension is still loose, the rubber crawler may need repairing due to excessive wear. Contact your dealer and ask for repair.




Fig. 8-12

7. If the tension is loose even after grease injection, it is necessary to replace either the rubber crawler or the grease adjuster. Contact your dealer for assistance.

- **Loosening the tension**

⚠ WARNING

- **Grease is under high pressure. If the nipple valve (Fig. 8-15, 1) is opened suddenly, grease could be ejected or the valve could blow, which could cause bodily injury.**
 - **Do not rely on valve appearance alone to determine whether or not grease has been discharged, but check that by measuring the tension of the rubber crawler.**
 - **Do not open the nipple valve (Fig. 8-15, 1) more than one turn.**
 - **It is very dangerous to discharge the grease by any procedure other than that described below.**
- If the tension of the rubber crawler cannot be loosened, contact your dealer and ask for repair.**

1. Remove the cover.




Fig. 8-13

2. Raise the machine with the implement and the safety blocks. Slowly loosen the nipple valve (**Fig. 8-15, 1**) and discharge the grease to adjust the rubber crawler tension and to achieve clearance (H) that is within the following range: 0.8 to 1.0 in. (20 to 25 mm).
3. Never loosen the nipple valve more than one turn.
(If the grease is not discharging properly, lower the machine and move the machine back and forth slightly.)

4. Tighten the nipple valve (**Fig. 8-15, 1**).

Tightening torque: 43.5 to 64.9 ft•lbf (59 to 88 N•m)

5. To check that the tension is proper, lower the machine and move the machine back and forth slightly.




Fig. 8-14




Fig. 8-15

6. Recheck the rubber crawler tension and readjust it if necessary.
7. Completely wipe away all of the discharged grease.

IMPORTANT

The rubber crawler is not grease-resistant.

Completely wipe away all of the grease because grease will shorten its service life.

8. Install the cover.

Replacing the rubber crawler

⚠ WARNING

- To replace the rubber crawler with a new one, work with a partner. You must operate the machine in response to signs from your partner.
 - Because the rubber crawler is replaced with the machine in a raised position, there is a danger that the machine may accidentally fall. Do not move any parts other than the rubber crawler to be replaced in doing the job.
 - The high internal pressure of the grease can cause the nipple valve to eject. When you loosen the nipple valve (Fig. 8-16, 1), do not loosen it more than one turn.
- At this point, do not loosen any parts other than the nipple valve (Fig. 8-16, 1). Also, do not turn your face toward the nipple valve (Fig. 8-16, 1).
- If the tension of the rubber crawler cannot be loosened by the procedure described here, ask your dealer to repair the rubber crawler.




Fig. 8-16

■ Replacing the rubber crawler

- Prepare a grease gun and steel pipes.

■ Removing the rubber crawler

⚠ WARNING

- It is very dangerous to discharge the grease by any procedure other than that described below.
- If the tension of the rubber crawler cannot be properly adjusted, ask your dealer to repair or replace the rubber crawler.
- When removing the rubber crawler, make sure that all of the grease has been completely discharged before turning the sprocket.

1. Raise the machine with the implement and the safety blocks.
To do this, slowly operate the control lever.
2. Loosen the nipple valve (Fig. 8-18, 1) little by little to gradually discharge the grease.
3. Never loosen the nipple valve (Fig. 8-18, 1) more than one turn.




Fig. 8-17





Fig. 8-18


4. Insert the steel pipes into the rubber crawler and turn the sprocket in the reverse direction. When the rubber crawler is separated from the idler by the steel pipes, slide the rubber crawler off.

**Fig. 8-19**

■ Installing the rubber crawler


1. Raise the machine with the implement and the safety blocks.

To do this, slowly operate the control lever.

**Fig. 8-20**

2. Engage the rubber crawler with the sprocket, and place the rubber crawler on the idler.
3. Rotate the sprocket in the reverse direction to push the rubber crawler in, and then stop rotating it.
4. Insert a steel pipe into the rubber crawler, and rotate the sprocket again to place the rubber crawler on the idler.
5. Stop rotating the sprocket, and confirm that the rubber crawler is securely positioned on both the sprocket and the idler.
6. Adjust the rubber crawler tension, referring to Section "Checking and adjusting the rubber crawler tension" on page 207.

7. Confirm that the rubber crawler is fully engaged with both the sprocket and the idler, and that the rubber crawler tension is sufficient. Then lower the machine to the ground.

**Fig. 8-21**

Checking and adjusting the steel crawler tension

⚠ WARNING

- When adjusting the steel crawler tension while raising the machine, do not support the machine with the implement only. The control levers could move or the hydraulic oil could flow out accidentally so that the machine would fall.
- When raising the machine, support it with safety blocks of sufficient strength.
- When the machine is being checked or adjusted by two persons, one must operate the machine in response to the signs from the other.

How the pins and bushings on the steel crawler will wear down depends on the working conditions and the ground conditions. Check the steel crawler tension from time to time to keep proper tension.

Check and adjust the steel crawler tension under the same conditions as in operation (for example, mud clogged condition if working in muddy ground.)

■ Checking the steel crawler

1. Raise the machine with the implement and the safety blocks. To do this, operate the control lever slowly.





Fig. 8-22

145799-00X

2. From a position that will be safe even if the machine should fall, measure the clearance between the bottom of the track frame and the upper surface of the shoe plate.

The tension is proper if the clearance is 5.91 to 6.30 in. (150 to 160 mm).



From the bottom of the track frame to the upper surface of the shoe plate.

004435-02EN00

Fig. 8-23

If the tension is improper, adjust it as follows:

■ Adjusting the steel crawler tension

• To increase the tension

Prepare a grease gun.

1. Remove the cover.




Fig. 8-24

2. Raise the machine with the implement and the safety blocks. Inject grease from the nipple valve with a grease gun until the steel crawler tension has achieved a clearance that is within the following range:
H=5.91 to 6.30 in. (150 to 160 mm).




Fig. 8-25




Fig. 8-26

3. To check that the tension is proper, lower the machine and move the machine back and forth slightly.
4. Check the steel crawler tension again. If the tension is improper, adjust it again.

5. Install the cover.

6. The tension can be adjusted until the clearance "a" is reduced to 0 in. (0 mm). If the tension is still loose after adjustment, the pin and the bushing should be replaced because they are probably worn excessively.

Ask your dealer to repair the crawler.




Fig. 8-27

- **Loosening the tension**

⚠ WARNING

- **Grease is under high pressure. If the nipple valve is opened suddenly, grease could be ejected or the valve could blow, which could cause bodily injury.**
- **Do not rely on valve appearance alone to determine whether or not grease has been discharged, but check that by measuring the tension of the steel crawler.**
Do not open the nipple valve (1) more than one turn.
- **It is very dangerous to discharge the grease by any procedure other than that described below. If the tension of the steel crawler cannot be loosened, ask your dealer to repair the steel crawler.**

1. Remove the cover.




Fig. 8-28

2. Raise the machine with the implement and the safety blocks. Slowly loosen the nipple valve and to discharge the grease to adjust the steel crawler tension and to achieve a clearance that is within the following range:
H=5.91 to 6.30 in. (150 to 160 mm).




Fig. 8-29

3. Never loosen the nipple valve more than one turn.
(If the grease is not discharging properly, lower the machine and move the machine back and forth slightly.)
4. Tighten the nipple valve.
Tightening torque: 43.5 to 64.9 ft•lbf (59 to 88 N•m)




Fig. 8-30

5. To check that the tension is proper, put down the machine and move the machine back and forth slightly.
6. Recheck the steel crawler tension and readjust it if necessary.
7. Completely wipe away all of the discharged grease.
8. Install the cover.

Replacing the bucket teeth and side cutter

■ Replacing the bucket teeth

When the bucket teeth are worn, replace them in accordance with the following procedure:

⚠ WARNING

- When replacing the bucket teeth, be careful not to move the implement by mistake for safety. Place the implement in a stable position, stop the engine, and ensure to move the lock levers to the lock position.
- During replacement operations, always wear safety gear such as safety goggles.

IMPORTANT

Replace the teeth before the point (Fig. 8-31, 1) is worn to the adapter (Fig. 8-31, 4).




Fig. 8-31

1. Place wood blocks on a level ground and lower the bucket to the ground with its bottom kept level as shown in Fig. 8-32.




Fig. 8-32

2. Strike out the locking pin (Fig. 8-31, 3) installed on the bucket with a hammer and punch to remove the point (Fig. 8-31, 1).

IMPORTANT

Do not strike the punch toward the rubber pin lock (Fig. 8-31, 2). Otherwise the rubber pin lock (Fig. 8-31, 2) may be damaged. Strike the tool toward the back of the pin.

3. Remove the rubber pin lock (Fig. 8-31, 2).
 4. Check the removed rubber pin lock (Fig. 8-31, 2) and locking pin (Fig. 8-31, 3).

Using the rubber pin lock (Fig. 8-31, 2) and locking pin (Fig. 8-31, 3) in the conditions below may cause the point (Fig. 8-31, 1) to come off during operation. Replace the applicable part with a new one.

- There is a crack in the rubber of the rubber pin lock (Fig. 8-31, 2) and the roller may come off.
- When pushed with a finger, the roller sinks in the rubber.
- With the lower side of the locking pin (Fig. 8-31, 3) aligned with the point bottom line, the dimension (Fig. 8-34, B) is equal to or more than 1/3 of the dimension (Fig. 8-34, A).




Fig. 8-33




Fig. 8-34

5. Clean the surface of adapter (**Fig. 8-31, 4**) with a tool such as a putty knife to remove the hard mud fixed on it.
6. Push the rubber pin lock (**Fig. 8-31, 2**) into the hole on the adapter (**Fig. 8-31, 4**) by hand or by a hammer.

IMPORTANT

Do not let the rubber pin lock (Fig. 8-31, 2**) come out of the adapter (**Fig. 8-31, 4**) surface.**

7. Install the point (**Fig. 8-31, 1**) to the adapter (**Fig. 8-31, 4**) and check that the rear surface of the pin hole on the point (**Fig. 8-31, 1**) is almost aligned with the rear surface of the pin hole on the adapter (**Fig. 8-31, 4**) when the point (**Fig. 8-31, 1**) is pushed strongly onto the adapter (**Fig. 8-31, 4**).
8. Insert the locking pin (**Fig. 8-31, 3**) into the pin hole on the point (**Fig. 8-31, 1**) and strike it so that the upper end of the locking pin (**Fig. 8-31, 3**) will be flush with the surface of the point.
 - Replace the rubber pin lock (**Fig. 8-31, 2**) and locking pin (**Fig. 8-31, 3**) with new ones at the same time when replacing the point (**Fig. 8-31, 1**). This prevents the point (**Fig. 8-31, 1**) from coming off.

■ Replacing the side cutter

Delay in replacing the side cutter could damage the bucket.

Replace the side cutter before the bucket is damaged.

Tightening torque:

651.01 to 795.65 ft•lbf (882.6 to 1078.7 N•m)

Screw lock agent: Loctite 262

- Replace the bolts, nuts and spring washers when replacing the side cutter.




Fig. 8-35

Replacing the bolt-on cutting edge (bolt-on cutting edge type)

■ Checking and replacing the bolt-on cutting edge for wear and damage

⚠ WARNING

When replacing the cutting edge, be careful not to move the blade by mistake for safety. Lowering the blade may cause serious accidents or bodily injury. When replacing, place a wood block under the blade to stabilize it and stop the engine.

When the cutting edge is worn or damaged, replace it as follows.

The cutting edge is divided into three plates (A/B/C), and if only one side is worn, the plates can be used by changing sides or positions as explained below.

- Plate **B** : Flip left/right
- Plate **A** and **C** : Flip left/right. Swap **A** and **C**.




Fig. 8-36

If all available sides are worn, replace them with new ones.

This section explains the procedure for replacing plate **A**.

The procedure is the same for other plates.

- Replace bolts, nuts and spring washers with new ones (Plates **A** and **C**: 4 sets each, Plate **B**: 7 sets each).
- There may be a gap of about 3 mm between the three plates, but this is normal.

1. Raise the blade and place a wood block under it.
2. Lower the blade onto the wood block.
3. Remove 4 mounting bolts (Fig. 8-38, 2), spring washers (Fig. 8-38, 3) and nuts (Fig. 8-38, 4) on plate **A** (Fig. 8-38, 1), and remove plate **A** (Fig. 8-38, 1).
4. Clean the mating surface.
5. Install a replacement plate with new 4 mounting bolts (Fig. 8-38, 2), spring washers (Fig. 8-38, 3) and nuts (Fig. 8-38, 4). Apply the crew lock agent to 4 bolts (Fig. 8-38, 2), and tighten the nuts (Fig. 8-38, 4) with the specified torque.
Tightening torque:
151.9 to 173.6 ft•lbf (205.8 to 235.2 N•m)
Screw lock agent:
Loctite 262 or K-965
6. Raise the blade and remove the wood block.
7. To ensure that the screw lock agent is effective, wait a day before working.




Fig. 8-37




Fig. 8-38

Maintenance, inspection and servicing of air conditioner

Daily maintenance and periodic inspection and servicing are required for the air conditioner to use it comfortably in the best condition.

Proper maintenance allows reduction in trouble and longer life of the air conditioner.

Exact inspection and servicing prevent trouble and reduce the cost for repair.

The air conditioner should also be checked and serviced at the time of a voluntary monthly inspection and a prescribed annual inspection of the machine.

It is recommended that the rubber hoses and electrical wires should be replaced every two years to use the air conditioner in the best condition.

Check points

- Abnormal sound and vibration of compressor
- Damage to compressor and condenser, and oil oozing in surrounding areas
- Abnormal sound and vibration of air conditioner unit
- Oil oozing on air conditioner hose and in unit connecting areas

The air conditioner should also be checked and serviced at the time of a voluntary monthly inspection and a prescribed annual inspection of the machine.

It is recommended that the rubber hoses and electrical wires should be replaced every two years to use the air conditioner in the best condition.

■ Cleaning the inner and outer air filters

1. Loosen the knob (Fig. 8-39, 2) of the air circulation filter cover (Fig. 8-39, 1) located under the left implement control lever to remove the air circulation filter cover (Fig. 8-39, 1).

2. Open the clip (Fig. 8-39, 3) of the air circulation filter to remove the air circulation filter.




Fig. 8-39

3. Hold the handle of the external filter (Fig. 8-40, 1) installed on the cabin panel located behind the seat to pull out the external filter (Fig. 8-40, 1).




Fig. 8-40

4. Never wash the air circulation filter with water or blow it with air. Turn the outside of the filter down and lightly tap it by hand to remove dust and dirt.

Remove any dust adhering to the fresh air filter, and blow it with compressed air (0.1 PSI (0.7 kPa) or less) from the inside to remove dust and dirt.

5. Install the cleaned filter.

Note:

If the function has not been recovered even after cleaning, replace the filter.

Cleaning the cabin floor

Clean the cabin floor periodically with a broom to remove dust and dirt, or wipe it off with a hard-wrung waste cloth.

Wash the floor with water around feet only. Do not throw water or use steam cleaning. Be careful not to get water especially onto the air conditioner duct, air circulation filter cover, engine stop switch, and fuse box cover, and place a cover over them if necessary.

Checking the gas spring


⚠ WARNING

High-pressure nitrogen gas is charged in the gas spring. Since wrong handling may cause a serious accident, strictly observe the following items.

- Do not disassemble.
- Keep flames away. Avoid putting it into fire.
- Do not drill, weld, and cut.
- Do not give a shock by hitting or rolling.
- Ask your dealer to dispose of.


The gas springs are used for the rear hood and right hood. In the following cases, ask your dealer to check and repair.

- Hood cannot be opened with a light force.
- Gas spring has oil leakage or gas leakage.
- Gas spring is damaged.



Rear hood

Fig. 8-41



Right hood

Fig. 8-42

Checking and cleaning DPF soot filter

Ask your dealer for checking and cleaning.

Checking before start-up

Check the items described below before starting the engine first in a day.

For details of the following items, refer to Section "Checking before start-up" on page 112 of "OPERATION" PART.

- Checking and replenishing the cooling water
- Checking and draining the water separator
- Checking and replenishing the engine oil
- Checking and replenishing the fuel in the fuel tank
- Checking and replenishing the hydraulic oil tank
- Checking and adjusting the fan belt tension
- Checking and replenishing the battery
- Greasing
- Checking the electrical equipment

Maintenance every 50 service hours

Greasing the swing gear and the swing bearing

⚠ WARNING

Do not swing the upperstructure while greasing.

Swing the upperstructure after each stage of greasing is completed to avoid serious bodily injury.

1. Using a grease gun, apply grease through the grease nipples shown in **Fig. 8-43**.
2. Swing the upperstructure in small increments and grease after each stop, until the upperstructure has made a full revolution.




Fig. 8-43

Draining the water and deposits in the fuel tank

⚠ WARNING

Keep sparks, flames and lit cigarettes away.

■ Things to prepare

- Container for fuel waste

1. Swing the upperstructure so that the drain hose (**Fig. 8-44, 1**) under the fuel tank is positioned in the middle of the right and left crawlers.
2. Loosen the bolts to move the cover (**Fig. 8-44, 2**) in the direction of an arrow.




Fig. 8-44

3. Put the container for fuel waste under the hose (**Fig. 8-44, 1**) for the drain cock.
4. Open the drain cock (**Fig. 8-44, 3**) to discharge the water and dirt deposits in the fuel tank from the drain hose (**Fig. 8-44, 1**). Take care that the fuel does not contact your body.
5. After clean fuel flows out, set the drain cock (**Fig. 8-44, 3**) to the close position, return the cover (**Fig. 8-44, 2**) and tighten the bolt.

Maintenance every 100 service hours

Perform the same maintenance as indicated for every 50 service hours.

Maintenance every 250 service hours

Also perform the maintenance every 50 service hours.

Checking and cleaning the air cleaner

⚠ WARNING

- Never attempt to clean and replace the air cleaner while the engine is running. Always stop the engine and allow it to cool first.
- Compressed air is used to clean the element. Always wear safety goggles to prevent injury to your eyes.
- The maximum compressed air pressure should be less than 100 PSI (0.7 MPa) for cleaning purposes.

■ Cleaning procedure for element

1. Open the right hood.
2. Pull down the lever (Fig. 8-45, 1) to remove the dust cup (Fig. 8-45, 2).




Fig. 8-45

3. Remove the outer element (Fig. 8-46, 1), and cover the inner element (Fig. 8-46, 2) with a clean waste cloth or pieces of tape to prevent dust and dirt from adhering to it.




Fig. 8-46

4. Clean the dust cup (Fig. 8-45, 2) and the inside of the body.
5. Blow the dry, compressed air [100 PSI (0.7 MPa) or less] from inside the element (Fig. 8-47, 3) along the pleats to initially remove the dirt. Then blow compressed air from outside the element along the pleats to remove dirt. Blow compressed air again from inside the element, to complete the dirt removal.




Fig. 8-47

6. After cleaning, illuminate the element (Fig. 8-48, 3) from inside with a light bulb and check it. If there are any small holes or thin areas, replace the element with a new one.




Fig. 8-48

IMPORTANT

- When cleaning the element, do not tap it or strike it against other objects. Otherwise the element may be damaged.
- Do not reuse the element if the pleat, gasket or seal is damaged.
- If clogging occurs (air cleaner clogging error is issued) soon after cleaning of the elements, replace the inner element.

7. Remove the protective cloth and tape used to cover the inner element.
8. Install the cleaned elements (Fig. 8-48, 3) to the air cleaner case.
9. Install the dust cup (Fig. 8-45, 2) so that the arrow mark will come on the front side and turn it clockwise. Push the lever (Fig. 8-45, 1) of the dust cup (Fig. 8-45, 2) to fix.
10. Close the right hood.

Checking and replenishing the lube oil for the travel reduction gearbox**⚠ WARNING**


- The gear oil and casing of the reduction gearbox are hot immediately after ceasing machine operation and can cause bodily injury.
Do not allow hot oil or the gearbox to contact your skin.
Replace oil after the oil and the gearbox have cooled sufficiently, if necessary.
- At operating temperature, the reduction gearbox is hot and its contents are under pressure.
In such condition, the oil or a plug may be ejected violently, causing bodily injury. Remove a plug slowly to gradually relieve the residual pressure.

■ Things to prepare

- Container for oil
 - Oil jug
1. Set the position of the drain port (Fig. 8-49, 2) to the lower side.
 2. Place a container receiving waste oil under the level port (Fig. 8-49, 1).
 3. Remove the level port plug using a hexagon wrench (0.3 in. (8 mm)) check that the oil level reaches the lower end of the level port.
 4. When the oil quantity is insufficient, ViO80-7: remove the plug of the oil supply port (Fig. 8-49, 3) and replenish gear oil through the oil supply port until gear oil overflows from the level port (Fig. 8-49, 1). SV100-7: replenish gear oil through the level port (Fig. 8-49, 1) until gear oil overflows from the level port (Fig. 8-49, 1). Refer to Section "4. Fueling, Oiling and

Greasing Based on Temperature Range" on page 197 for the oil to be used.

ViO80-7



SV100-7




Fig. 8-49

5. Install the plug.

Tightening torque

- ViO80-7:
36.1 to 50.6 ft•lbf (49.0 to 68.6 N•m)
- SV100-7:
57.9 to 86.8 ft•lbf (78.5 to 117.7 N•m)

Checking and cleaning the radiator, oil cooler, air conditioning condenser, and fuel cooler

⚠ WARNING

- Checking and cleaning these components while the engine is running are dangerous. Always stop the engine before checking and cleaning.
- Compressed air may scatter objects around these components and it is dangerous. Check that there are no other persons nearby, and always wear protective gear such as safety goggles.
- The maximum compressed air pressure should be less than 100 PSI (0.7 MPa).

1. Open the right hood.
2. Clean off any mud, dirt or leaves clogged between the fins of the air conditioning condenser (Fig. 8-50, 1) and fuel cooler (Fig. 8-50, 2) using a soft brush.
3. Loosen the wing screw (Fig. 8-50, 3) and open the air conditioning condenser.




Fig. 8-50

4. Clean off any mud, dirt or leaves clogged between the fins of the radiator (**Fig. 8-51, 4**) and oil cooler (**Fig. 8-51, 5**) using a soft brush.




Fig. 8-51

IMPORTANT

When compressed air is used for cleaning, blow it from the engine side at a distance from the fins. A damaged fin will cause water and oil leaks and overheating.

5. Check the fins of the radiator, oil cooler, air conditioning condenser, and fuel cooler for inclination or damage.
6. Return the air conditioning condenser and close the right hood.

Checking and adjusting the fan belt and air conditioner belt

⚠ WARNING

- Stop the engine, take the key out of the starter switch, and then place “DO NOT USE” tag on the switch section.
- Immediately after the engine has stopped, the engine and surrounding area are very hot. After the engine has cooled down, perform the check and adjustment.

■ Checking

1. Open the rear hood.
2. Remove the two bolts (**Fig. 8-52, 1**) and guard (**Fig. 8-52, 2**).




Fig. 8-52

3. Remove the cover (**Fig. 8-53, 1**) under the engine at the rear of the upperstructure by loosening the fixing bolt (**Fig. 8-53, 2**).




Fig. 8-53

4. Check the fan belt and air conditioner belt for damage, and the pulleys for damage and corrosion. If any abnormality is found on the pulleys, ask your dealer for repair.

5. Measure the belt tension by pushing the measurement point on each of the fan belt and air conditioner belt with a finger, etc.

	Fan belt	Air conditioner belt
Measurement point	Fig. 8-54 3	Fig. 8-54 4
Pushing load	22.1 lbf (98.1 N)	22.1 lbf (98.1 N)
Adequate tension (In use)	1.0 to 1.1 in. (25.7 to 27.8 mm)	0.88 to 0.94 in. (22.3 to 23.9 mm)
Adequate tension (New)	0.88 to 0.99 in. (22.3 to 25.1 mm)	0.78 to 0.86 in. (19.7 to 21.8 mm)




Fig. 8-54

- 6. Adjust the tension if necessary.
- 7. With the adequate tension, check that the belts do not contact the V-groove bottom of any pulley.
- 8. If any belt is elongated and cannot be adjusted, if damage such as a scratch and crack occurs, or if any belt contacts the V-groove bottom of any pulley, replace the belt with a new one.

Fan belt (Part number: 172B69-11200)
Air conditioner belt (Part number: 172B69-18100)

9. When no abnormality is found on the belts and pulleys, reinstall the guard (**Fig. 8-52, 2**) and close the rear hood.

■ Adjusting the fan belt

- 1. Loosen the generator mounting bolts (**Fig. 8-55, 5**) and (**Fig. 8-55, 6**).
- 2. Loosen the adjuster set nut (**Fig. 8-55, 7**).
- 3. Turning the adjuster bolt (**Fig. 8-55, 8**) clockwise tensions the belt, and turning it counterclockwise loosens the belt.




Fig. 8-55

- 4. Adjust the belt to the adequate tension, and tighten the generator mounting bolts (**Fig. 8-55, 5**) and (**Fig. 8-55, 6**).
- 5. Tighten the adjuster set nut (**Fig. 8-55, 7**).

■ Adjusting the air conditioner belt

- 1. Loosen the compressor mounting bolts (**Fig. 8-56, 9**) and (**Fig. 8-56, 10**).
- 2. Loosen the adjuster set nut (**Fig. 8-56, 11**).
- 3. Turning the adjuster bolt (**Fig. 8-56, 12**) clockwise tensions the belt, and turning it counterclockwise loosens the belt.




Fig. 8-56

- 4. Adjust the belt to the adequate tension, and tighten the compressor mounting bolts (**Fig. 8-56, 9**) and (**Fig. 8-56, 10**).
- 5. Tighten the adjuster set nut (**Fig. 8-56, 11**).

Maintenance every 500 service hours

Also perform the maintenance every 50, 100, and 250 service hours.

Checking and maintaining the pre-filter

⚠ WARNING

- Be sure to keep flames such as lit cigarettes away.
- Only after the engine has cooled down sufficiently, check and maintain the pre-filter.
- The fuel leaked or spilled onto hot surfaces or electrical components may cause a fire.
- Drain the fuel before removing the pre-filter cup.

■ Replacing the pre-filter element

Things to prepare

- Container for fuel wastes
- Filter wrench (Part number: 129A00-92750)
- New fuel pre-filter element

List of consumables: Refer to page 196.

1. Drain the fuel from the pre-filter.
Checking and draining the pre-filter: Refer to page 113.
2. Turn the fuel cock (Fig. 8-57, 1) to OFF position.
3. Disconnect the water detection sensor coupler (Fig. 8-57, 2).
4. Turn the cup (Fig. 8-57, 3) counterclockwise with a filter wrench LO, and remove it while preventing the fuel from being spilled. Completely wipe off any spilled fuel.
5. Remove the element (Fig. 8-57, 4) and O-ring (Fig. 8-57, 5).

6. Wash the inside of the cup (Fig. 8-57, 3) and the float (Fig. 8-57, 6) with new fuel oil thoroughly.
7. Install a new element to the pre-filter main body.
8. Check the O-ring (Fig. 8-57, 5) state, replace it with a new one if necessary, and install it to the cup (Fig. 8-57, 3).
O-ring (Part number: 129A00-55740)
9. Insert the float (Fig. 8-57, 6) into the cup (Fig. 8-57, 3), and reinstall them to the pre-filter main body. For installation, turn them to the right by hand without using any tool.
10. Connect the water detection sensor coupler (Fig. 8-57, 2).
11. Bleed the air from the fuel.
How to bleed the air: Refer to page 228.
12. Check for fuel leak and other problems.
13. Close the right hood.




Fig. 8-57

145629-00EN

Replacing the fuel filter and bleeding the air from the fuel passage

⚠ WARNING

- Be sure to keep flames such as lit cigarettes away.
- Immediately after the engine has stopped, the engine components are very hot. Only after the engine has cooled down, perform the operations.
- The fuel leaked or spilled onto hot surfaces or electrical components may cause a fire.

■ Replacing the fuel filter

Things to prepare

- Container for fuel wastes
- Filter wrench (Part number: 119640-92750)
- New fuel filter

List of consumables: Refer to page 196.

1. Open the rear hood.
2. Place the container for fuel under the fuel filter (**Fig. 8-58**).
3. Turn the fuel filter counterclockwise to remove with a filter wrench.
4. Clean the fuel filter mount. Fill up a new filter with fuel and install it with the engine oil applied to its seal surface.
5. After the fuel filter has been replaced, bleed the air.
How to bleed the air: Refer to page 228.
6. After bleeding the air completely, start the engine to check for fuel leak and other problems.

If no problem is found, stop the engine and close the rear hood.

IMPORTANT

To prevent the fuel filter from being overtightened, turn it slightly until the mount contacts the seal surface, and then additionally tighten it 2/3 turns.




Fig. 8-58

■ How to bleed the air

The machine is equipped with the automatic air bleeding device (solenoid pump). Bleed the air in the procedure below.

1. Fill up the fuel tank.
2. Move the lock lever to the lock position, and fully turn the engine control dial clockwise.
3. Turn the key to the "ON" position to energize for approximately 25 to 30 seconds. (Normally, the air has been bled in 25 to 30 seconds.)
4. Turn the key to the "START" position to start the engine.

IMPORTANT

If starting fails, turn the key to the "OFF" position, and wait for 1 minute or longer. Then, turn the key again to the "START" position.

- Bleed the air in the same way also in case of run-out of fuel.
After the engine starts, if it runs irregularly, turn the key to the "OFF" position, wait for one minute or more and turn the key to the "START" position again.

Replacing the engine oil and engine oil filter

⚠ WARNING

Immediately after the engine has stopped, the engine components are very hot. Only after the engine has cooled down, replace the oil.

■ Things to prepare

- Engine oil: 11.8 Qts. (11.2 L)
- Container for waste oil
- Filter wrench (Part number: 119640-92750)
- New engine oil filter

List of consumables: Refer to page 196.

1. Swing the upperstructure so that the drain plug (**Fig. 8-59, P**) at the bottom of the engine will be positioned in the middle of the right and left crawlers.
2. Place the container for waste oil under the drain plug (**Fig. 8-59, P**) and hose at the bottom of the machine body.
3. Slowly remove the drain plug (**Fig. 8-59, P**) using a tool with a width across flats of 0.75 in. (19 mm) so that the oil will not splash your body, and drain the waste oil. Check the waste oil, and contact your dealer if a lot of metallic particles or foreign objects are mixed in it.




Fig. 8-59

4. Reinstall the drain plug (**Fig. 8-59, P**).

5. Turn the oil filter (cartridge) (**Fig. 8-60, 1**) counterclockwise with a filter wrench to remove.

After removing the oil filter (**Fig. 8-60, 1**), wait for 10 to 15 minutes.




Fig. 8-60

6. Clean the filter mount and apply the engine oil (or apply grease lightly) to the seal surface of a new oil filter (**Fig. 8-60, 1**) and install the filter.
7. When installing the filter, additionally turn it 2/3 turns after the seal surface has contacted the filter mount.
8. After replacing the oil filter (**Fig. 8-60, 1**), add engine oil to the upper limit mark on the oil dipstick through the oil supply port (**Fig. 8-60, F**).
9. Allow the engine to run at low idle speed for a while and then stop the engine. After that, check that the oil level exceeds the midpoint between the upper and lower limit marks on the oil dipstick. Refer to "Checking before start-up" on page 112.
10. Reinstall and tighten the oil supply port cap securely.

Replace the engine oil and oil filter 1 year after the previous replacement even if the service hours have not reached 500 hours.

Also replace them when the service hours have reached 500 hours, even if 1 year has not passed.

Replacing the air cleaner element

⚠ WARNING

Replacing components while the engine is running is dangerous. Be sure to stop the engine before replacing any component.

■ Things to prepare

- New air cleaner element

List of consumables: Refer to page 196.

1. Open the right hood.
2. Remove the clip (Fig. 8-61, 1) and then the dust cup (Fig. 8-61, 2).
3. Remove the outer element (Fig. 8-62, 3), and cover the inner element (Fig. 8-62, 4) with a clean waste cloth or tape so that no dust or dirt can adhere to it.
4. Clean the inside of the dust cup (Fig. 8-61, 2) and the body. Remove the waste cloth or tape used to cover the inner element (Fig. 8-62, 4).
5. Install a new element (Fig. 8-62, 3).
6. Reinstall the dust cup (Fig. 8-61, 2), while checking the arrow on it.
7. Close the right hood.

IMPORTANT

If clogging occurs (air cleaner clogging error is issued) soon after replacement of the element, replace the inner element.




Fig. 8-61




Fig. 8-62

Replacing the hydraulic oil return filter

⚠ WARNING

- The hydraulic oil and the tank surface are very hot immediately after operations. Replacing the filter in such condition is dangerous, and may cause bodily injury such as a burn. Wait until the tank has cooled enough to permit you to touch its surface with your bare hand, and then start the operation.
- Removing the tank cap carelessly may cause the hydraulic oil to spout out because of the pressure inside the tank. Slowly and evenly loosen the 3 mounting bolts, and then remove the cap.


■ Things to prepare

- New hydraulic oil return filter element


List of consumables: Refer to page 196.

1. Open the front cover (right), and clean the hydraulic oil tank cover (Fig. 8-63, 1) and its surrounding area with a waste cloth or other.
2. Loosen the hose bands (Fig. 8-63, 3) fixing the return hoses (Fig. 8-63, 2), and disconnect the return hoses (Fig. 8-63, 2).

3. Slowly and evenly loosen the 3 bolts (**Fig. 8-63, 4**) on the hydraulic oil tank cap, release the internal pressure, and then remove the cover (**Fig. 8-63, 1**) and hydraulic oil return filter together.

**Fig. 8-63**

4. Separate the return pipe (**Fig. 8-64, 2**) and return filter (**Fig. 8-64, 1**) with a spanner.

**Fig. 8-64**

5. Install a new filter to the return pipe (**Fig. 8-64, 2**).
6. Wipe the cap mount on the hydraulic oil tank with a waste cloth and check the O-ring. If the O-ring is damaged, replace it with a new one and then reinstall the cover (**Fig. 8-63, 1**).
O-ring (Part number: 24321-001350)
7. Reinstall the return hoses (**Fig. 8-63, 2**), and tighten the hose bands (**Fig. 8-63, 3**).
8. Bleed the air from the hydraulic circuit, and check the oil level in the hydraulic oil tank. Refer to "Hydraulic system" on page 194.
9. Close the front cover (right).

IMPORTANT

- Do not allow any dust or dirt to enter the hydraulic tank when installing the cap.
- Reinstall the hose bands to the return hose so that the fastened portions will face in the opposite directions.

Replacing the hydraulic oil breather filter element

■ Things to prepare

- New hydraulic oil breather filter element
List of consumables: Refer to page 196.

1. Open the front cover (right).
2. Turn the knob (**Fig. 8-65, 1**) on the breather filter cover counterclockwise, and remove the breather filter cover (**Fig. 8-65, 2**).




Fig. 8-65

3. Replace the breather filter element (**Fig. 8-65, 3**) with a new one.
4. Reinstall the filter cover (**Fig. 8-65, 2**), and fix it by turning the knob (**Fig. 8-65, 1**) clockwise.
5. Close the front cover (right).

Maintenance every 1000 service hours

Also perform the maintenance every 50, 100, 250 and 500 service hours.

Replacing the lube oil for the travel reduction gearbox

⚠ WARNING


- The oil and reduction gearbox case are very hot immediately after the operations. Replacing the oil immediately is dangerous, and may cause bodily injury such as a burn.
Wait until the reduction gearbox case has cooled enough to permit you to touch it with your bare hand, and then start the operation.
- Otherwise, the oil may spout out or plug may be ejected suddenly. Loosen the plug slowly to release the pressure inside the tank.

■ Things to prepare


- Container for waste oil
- Gear oil
ViO80-7 : 1.16 Qts. (1.1 L) for right and left each
SV100-7 : 2.22 Qts. (2.1 L) for right and left each

1. The drain port (**Fig. 8-66, 2**) should come to the lower side.

ViO80-7



SV100-7



152872-00X

Fig. 8-66

2. Put the container for waste oil under the drain port (**Fig. 8-66, 2**).
3. Remove the plugs from the drain port (**Fig. 8-66, 2**) and level port (**Fig. 8-66, 1**) with a hexagon socket screw key [0.31 in. (8 mm)] to drain the waste oil.
4. After draining the waste oil, reinstall the plug to the drain port (**Fig. 8-66, 2**).

Tightening torque

- ViO80-7: 36.1 to 50.6 ft•lbf
(49.0 to 68.6 N•m)
 - SV100-7: 57.9 to 86.8 ft•lbf
(78.5 to 117.7 N•m)
5. For the ViO80-7, remove the plug from the oil supply port (**Fig. 8-66, 3**), and add the gear oil through the oil supply port (**Fig. 8-66, 3**) to the specified level.
For the SV100-7, add the gear oil through the level port (**Fig. 8-66, 1**) to the specified level.

For the oil to be used, refer to "Fueling, Oiling and Greasing Based on Temperature Range" (page 197).

6. After the gear oil overflows from the level port (**Fig. 8-66, 1**), reinstall the plug to the level port (**Fig. 8-66, 1**), and for ViO80-7, reinstall the plug to the oil supply port (**Fig. 8-66, 3**).

Tightening torque

- ViO80-7: 36.1 to 50.6 ft•lbf
(49.0 to 68.6 N•m)
- SV100-7: 57.9 to 86.8 ft•lbf
(78.5 to 117.7 N•m)

Replacing the oil in the hydraulic oil tank and cleaning the suction filter

⚠ WARNING

- The oil and tank surface are very hot immediately after the operations. Replacing the oil immediately is dangerous, and may cause bodily injury such as a burn. Wait until the tank has cooled enough to permit you to touch its surface with your bare hand, and then start the operation.
- First slowly turn the oil supply port cap to release the internal pressure, and then remove the cap carefully.
- Removing the tank cap carelessly may eject the cap suddenly because of the spring force holding the filter. Also, the hydraulic oil may spout out because of the pressure inside the tank. Slowly and diagonally loosen the 4 mounting bolts and then remove the cap.

■ Things to prepare

- Container for waste oil
 - Hydraulic oil 15.8 Gals. (60 L) [When the oil is drained completely from all of the hydraulic equipment, pipes and hoses, 29.6 Gals. (112 L)].
 - O-ring for drain plug (Part number: 24341-000300)
1. Swing the upperstructure so that the drain plug (Fig. 8-68, P) at the bottom of the hydraulic tank will be positioned in the middle of the right and left crawlers.
 2. Retract the bucket and arm cylinders to their stroke ends, lower the boom and put the bucket teeth on the ground.

3. Put the blade on the ground and stop the engine.




Fig. 8-67

4. Remove the 4 bolts (Fig. 8-68, 1) on the lower side of the upperstructure, and then the cover (Fig. 8-68, 2).
5. Put the container for waste oil under the drain plug (Fig. 8-68, P).
6. Remove the drain plug (Fig. 8-68, P) and drain the waste oil.

When removing the drain plug (Fig. 8-68, P), take care that the oil does not splash your body.




Fig. 8-68

7. Open the front cover (right), and remove the pilot block (Fig. 8-69, 1).
8. Clean the cap mount on the upper side of the hydraulic tank with a waste cloth or other, and slowly loosen the bolt to remove the cover (Fig. 8-69, 2).





Fig. 8-69

9. Degrease and wash the threads of the drain plug, and replace the O-ring with a new one.
10. After draining, tighten the drain plug (**Fig. 8-70, P**).
Tightening torque: 79.6 ft•lbf (107.9 N•m)


**Fig. 8-70**

11. Take out the filter (**Fig. 8-70, 3**).
12. Remove dust and dirt adhering to the filter, and wash it with cleaning oil or diesel oil.
13. Check the filter and its O-ring for damage or flaw, replace the filter with a new one if necessary, and install it to the hydraulic tank.

IMPORTANT

Do not allow any dust or dirt to enter the tank when installing the filter.

14. Add the oil to the specified level.
Check the oil level with the oil level gauge (**Fig. 8-71, 1**) and do not add the oil beyond 20 mm above the midpoint between the upper and lower limit marks on the oil level gauge (**Fig. 8-71, 1**).
Refer to "Fueling, Oiling and Greasing Based on Temperature Range" on page 197.

**Fig. 8-71**

15. Wipe the cap mount with a waste cloth or other and check the O-ring.
If any flaw is found, replace it with a new one.
O-ring (Part number: 24321-001700)
16. Reinstall the cap.
17. After replacing the oil, bleed the air from the hydraulic circuit, and check the oil level in the hydraulic oil tank.
Refer to "Hydraulic system" on page 194.
18. Close the front cover (right).

Replacing the line filter

⚠ WARNING

The oil is very hot immediately after the implement stops operating. Do not replace the filter immediately after stop. After the oil has cooled enough, replace the filter.

■ Things to prepare

- Container for waste oil
 - New hydraulic oil line filter element
- List of consumables: Refer to page 196.

1. Release the pressure from the hydraulic circuit.
For how to release the pressure, refer to Handling accumulator: on page 159.
2. Remove the left hood (Fig. 8-72, 1).
3. Remove the guard L (Fig. 8-72, 2).




Fig. 8-72

4. Apply a spanner onto the hexagon at the bottom of the case (Fig. 8-73, 6), and loosen the case (Fig. 8-73, 6) by turning the spanner counterclockwise viewed from the bottom.




Fig. 8-73

5. Even after the case (Fig. 8-74, 6) is removed, the element (Fig. 8-74, 4) remains in the head (Fig. 8-74, 3). Pull the element (Fig. 8-74, 4) out of the head (Fig. 8-74, 3) to remove.




Fig. 8-74

6. Wash the case (Fig. 8-74, 6).
7. Insert a new element into the head (Fig. 8-74, 3).
8. Replace the O-ring (Fig. 8-74, 5) attached to the case (Fig. 8-74, 6) with a new one.
9. Screw the case (Fig. 8-74, 6) into the head (Fig. 8-74, 3).
Tightening torque:
18.4 to 25.8 ft·lbf (25 to 35 N·m)
10. Start the engine and check for oil leak.
11. Reinstall the guard L (Fig. 8-72, 2) and left hood (Fig. 8-72, 1).

Checking and adjusting the intake/exhaust valve clearances

Ask your dealer for checking and adjusting.

Maintenance every 1500 service hours

Also perform the maintenance every 50, 100, 250 and 500 service hours.

Checking the crankcase breather system

Ask your dealer for checking.

Cleaning the EGR cooler

Ask your dealer for cleaning.

Maintenance every 2000 service hours

Also perform the maintenance every 50, 100, 250, 500 and 1000 service hours.

Replacing the engine cooling water

WARNING

- The cooling water is very hot immediately after the engine has stopped. Draining the cooling water immediately after stop may cause burns. Only after the engine has cooled down, start the operation.
- Cleaning takes place while the engine is running. Therefore, it is very dangerous for persons staying behind the machine, if the machine starts moving. Also, with the rear hood being opened, these persons may contact the radiator fan.
Never step into the area behind the machine while the engine is running.
- Do not remove the radiator cap while the water temperature in the radiator is high. Hot water may spout out. After the cooling water has cooled down, first slowly turn the radiator cap to release the internal pressure, and then remove the cap.

■ Table of mixing ratio of anti-freeze to water

At the delivery from the factory, the concentration of anti-freeze is 51 %.

Lowest temperature [°F (°C)]	5 (-15)	-4 (-20)	-13 (-25)	-22 (-30)	-31 (-35)	-40 (-40)
Concentration of anti-freeze (%)	30	35	40	45	50	55

⚠ WARNING

- Anti-freeze is flammable. Keep flames away from anti-freeze.
- Wear the protective gear not to allow anti-freeze to get into your eyes or contact your skin. If the cooling water gets into your eyes or contacts your skin, flush with water to remove it completely.

IMPORTANT

- Use tap water to mix. To use water from a river, a well or a private water-supply system, consult your dealer.
- Though the mixing ratio of anti-freeze differs with the ambient temperature, at least 30 % of anti-freeze by volume is required to obtain anti-corrosive effect.
- Determine the mixing ratio of anti-freeze on the basis of the lowest temperature in the past, referring to the ratio table. Actually, set a temperature approximately 50 °F (10 °C) lower than the lowest temperature.
- Use a densitometer to control the mixing ratio.
- Park the machine on level ground to replace the cooling water.

■ Things to prepare

- Cooling water 3.5 Gals. (13.3 L)
- Container for waste fluid

1. Swing the upperstructure so that the drain plug (**Fig. 8-75, P**) will be positioned in the middle of the right and left crawlers.
2. Remove the cover (**Fig. 8-75, 1**) located under the rear of the upperstructure.




Fig. 8-75

3. Put the container for waste fluid under the drain plug (**Fig. 8-75, P**).
4. Slowly remove the drain plug (**Fig. 8-75, P**) using a tool with a width across flats of 0.75 in. (19 mm) to drain the cooling water.
5. Open the front cover (right), and slowly turn the radiator cap (**Fig. 8-76, 1**) to remove.




Fig. 8-76

6. After the cooling water has been drained, reinstall the drain plug (**Fig. 8-75, P**).
7. Remove the cooling water sub-tank (**Fig. 8-76, 2**), and drain the cooling water from the sub-tank.
8. Reinstall the cooling water sub-tank (**Fig. 8-76, 2**), and add the cooling water up to the FULL line.

9. Pour the cooling water into the radiator to fill it up.
10. To bleed the air from the cooling water system, allow the engine to run at low idle speed for 5 to 6 minutes and then at high speed without load for additional 5 to 6 minutes. [While the engine is running, keep the radiator cap (**Fig. 8-76, 1**) removed.]
11. Approximately 5 minutes after stopping the engine, pour the cooling water into the radiator through the water supply port up to almost the port opening, and securely tighten the radiator cap (**Fig. 8-76, 1**).
12. Check the level in the sub-tank (**Fig. 8-76, 2**), and if it is below the FULL line, pour the cooling water.
13. Reinstall the cover (**Fig. 8-75, 1**), and close the hoods.

Checking the accumulator

Refer to "Handling accumulator" on page 159.

Checking and replacing the fuel, cooling water, and lubricating oil hoses

Ask your dealer for checking and replacing.

Lapping the intake and exhaust valve seats

Ask your dealer for lapping.

Maintenance every 3000 service hours

Also perform the maintenance every 50, 100, 250, 500, 1000 and 1500 service hours.

Checking, cleaning and testing EGR valves

Ask your dealer for checking, cleaning and testing.

Checking and testing intake throttle valve

Ask your dealer for checking and testing.

Checking and cleaning the injector

Ask your dealer for checking and cleaning.

Maintenance every 9000 service hours

Also perform the maintenance every 50, 100, 250, 500, 1000, 1500 and 3000 service hours.

Replacing the diesel particulate filter (DPF)

Ask your dealer for replacing.